



Low Range
Hardness

50 Test Strips

Code 2981

Insta-Test[®] ANALYTIC

Low Range Hardness ppm (gpg)



Using a cup-size sample, immerse strip and remove with **pad face up**. **DO NOT SHAKE OFF EXCESS WATER**. Wait 15 seconds and compare to color chart. Discard strip after 30 seconds.



- | Keep wet fingers out of the bottle.
- | Cap bottle tightly.
- | Store in a cool, dry place.

LaMotte Company
Chestertown, Maryland 21620 USA
<http://www.lamotte.com>

